

# Thermoskin Air Pump Alarm

What to do if the airpumps' alarm goes off?

1. Check whether there is power failure on either pump
2. Check the pressure displayed on the screen by the relevant pump.  
The two pumps should indicate a pressure between 100 and 200 Pascal.

If either of the situations occur please take the following action.

With power failure:

1. Take steps to ensure both pumps have a good constant supply of power.

With low pressure:

1. Check all blue and white hoses to make sure they are still connected properly.
2. Check if all roofskins are still inflated.



Inflated



Not Inflated

3. Check if filters in the pump door need to be cleaned.

If pressure remains low or does not improve within one hour, call +44 1604 593820.

For other countries:

Netherlands	+ 31 77 426 24 44
Belgium	+ 32 11 81 21 51
Germany	+ 49 3222 10 90 17 6
France	+ 33 15581 01 83
Poland	+ 48 713 25 8433

